

General instructions

This unit has a **built-in rechargeable battery**. When the battery is completely empty please plug the power adapter into a suitable socket outlet. After the battery is fully charged please unplug carefully the power cord.

Battery charge time: **5-6hrs (PRT-8) and 7-8hrs (PRT-12)**.
Before using the unit for **the first time charge the battery for about 8hrs (PRT-8) & 10hrs (PRT-12)**.

The unit's playback time is **up to 8hrs (PRT-8) & 12hrs (PRT-12)** depending on the volume level and use of additional features, e.g. LED light, of the speaker.

Note: To get the best performance and prolong battery's life, please charge the battery when it is completely empty. Do not leave the unit without being used or charged for a very long time. In order to prolong the life of the battery please charge and use the unit periodically.


Warnings

1. The **lightning flash** with the arrowhead symbol within an equilateral triangle alerts the user to the presence of un-insulated dangerous voltage within the product's enclosure that could cause electric shock.

2. The **exclamation mark** within an equilateral triangle alerts the user to the presence of important operating and maintenance instructions as well as warnings in the user's manual or on the product.



REMOTE CONTROL



D & J DAMKALIDIS SA
44 Zefyrou str., P. Faliro, PC 17564
Support: 210 9410888
email: desk@damkalidis.gr
www.crystalaudio.gr

CE
DECLARATION OF CONFORMITY
Radio equipment and telecommunications terminal equipment, Directive 2014/53/EU
Crystal Audio hereby declares that the product, PRT Portable Speaker True Wireless Stereo, is in conformity with provisions of the Directive 2014/53/EU. The complete text of the Declaration of conformity can be found on the following webpage: www.CrystalAudio.gr

Designed in Europe by Crystal Audio - Assembled in China with the highest quality standards.
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG Inc. and any use of such marks by Crystal Audio is under license. Other trademarks and trade names are those of their respective owners.

www.CrystalAudio.com

CRYSTALAUDIO

TRUE WIRELESS STEREO PORTABLE SPEAKERS



- Quick Guide -



Thank you for purchasing Crystal Audio PRT speakers

PRT speakers are **innovative portable, battery powered, speakers** equipped with **TWS & Bluetooth wireless streaming** capabilities. Small and portable yet powerful, they produce an **unexpectedly deep and clear bass** for their dimension.


TECHNICAL SPECIFICATIONS:

	PRT-8	PRT-12
Woofer:	8inch, Long Throw	12inch, Long Throw
Sensitivity:	96dB@2,83V/1m	102dB@2,83V/1m
Twitter:	1inch, Soft Dome	1inch, Soft Dome
Sensitivity:	98dB@2,83V/1m	100dB@2,83V/1m
Battery:	9V / 3x 2200mAh (25Whr)	12V / 4500mAh (54Whr)
Power Supply:	30W	45W
Pow. Sup. Voltage:	15V	15V
Pow. Sup. Current:	2A	3A

CONNECTIVITY FEATURES:

- Bluetooth® v4.2
- USB port
- SD/microSD slot
- AUX In
- Microphone In
- Guitar/Keyboards In
- 12V DC External Battery In


REAR PANEL



PRT-8
PORTABLE WIRELESS SPEAKER
TWS - True Wireless Stereo
Power Supply: 30W
www.crystalaudio.com

1 Control the unit


Control PRT speakers by the unit's rear panel keys.



2 Pair it (Bluetooth®)

You can pair PRT speakers with any Bluetooth enabled device (phone/tablet).

1. Enable Bluetooth mode in your phone or tablet.
2. Turn ON the speaker from the relevant switch on the back panel.



3. The speaker starts by default in Bluetooth mode. The Bluetooth indication (bLUE) will be shown on the screen of the back panel.
4. Go to BT connections (in your phone or tablet) and perform a Device Scan for all the available BT devices.


3 Add a second speaker (TWS)

You can connect your PRT speaker with another PRT speaker and enjoy a True Wireless Stereo experience.

1. Turn ON speaker no1 (Master speaker).




2. Press TWS button (twice) to activate MASTER mode (screen message MASR)




MASR

3. Turn ON speaker no2 (Slave speaker).



4. Press TWS button (once) to activate SLAVE mode (SLAV message will flash on the speaker's screen).



SLAV

5. Wait for 15-20 seconds until "CONN" message appears on the MASTER speaker. The speakers will pair automatically and the SLAV message will stop flashing on the SLAVE speaker.
6. Connect your audio device to the MASTER speaker and enjoy TRUE WIRELESS STEREO sound.
7. To exit TWS mode place the speaker in MASTER mode and then press MODE button.



- When pairing two speakers the right channel would be the **MASTER speaker** and the left channel would be the **SLAVE speaker**.

- Once the speakers have been successfully paired, to re-use them as a pair **turn on SLAVE speaker first** and then **turn on MASTER speaker**.

4 Connect your playback devices

Apart from the wireless connection (Bluetooth) you can connect PRT speakers to your playback devices via:

1. **AUX:** Connect to the headphone output of your device
2. **USB:** Play songs directly from your USB flash drive
3. **SD Card:** Play songs directly from your SD card
4. **MicroSD Card:** Play songs directly from your micro SD card



5 Select Modes

Use the Mode selector on the unit, to cycle between the various available inputs/modes:




Note: Every time you turn on the speaker it starts by default in Bluetooth mode.

In case you are requested to enter a PIN code, please enter **0000**.

6 Plug in your wired Microphone, guitar or keyboards*

* Not included. Make sure you adjust the respective volume switch accordingly.



Tip:


Press **Mic Priority** button to override music and give the Microphone sound priority.



7 Connect your wireless Microphone

Connect the supplied Microphone with the speaker wirelessly.


1. Turn On the Microphone by placing the switch in the top position.
2. The Microphone will connect to the speaker automatically.*



* Make sure you adjust the MIC volume switch accordingly.

8 Switch on/off the LED light

Push the LIGHTS switch on the back to switch on/off the LED lights. The colors of the lights are changing during the playback.




Tip:

You might want to have the lights turned off in order to preserve battery life.

9 Add external battery

You have the option to add an external battery (12V) on the unit's rear panel in order to have more playback hours and keep the party going on!



10 Charge the unit

Please use the supplied adapter to charge the battery of the speaker.



11 Check battery status

You can check the battery life on the back of the unit.

The indications will let you know when:

- battery is **fully charged**
- battery is **being charged**
- battery **needs to be charged**

